



Belt Drive Turntable Set Up Instructions

The platter for your turntable was removed prior to shipping to prevent damage. Please follow these instructions to install the drive belt and place the platter back on your turntable. Your turntable may vary slightly from this example.

1. Place the turntable platter upside down on a solid surface. Make sure the drive belt is looped around the inner platter rim.



2. Locate the center spindle and place the platter on the spindle. Gently press down on the platter to make sure it is seated.



3. Rotate the platter until you can see the motor. Pull the belt away from the platter and place it around the motor pulley.

